

SCHEDULE OF DEFAULT PIPELINE FLOW DIRECTION

27 JUNE 2017



Version: 3

© 2017 Australian Energy Market Operator Ltd (AEMO). All rights reserved.

Important Notice

This Schedule for Default Pipeline Flow has been prepared by Australian Energy Market Operator (AEMO) as the Bulletin Board Operator guidance on the use of the GBB Website as at the date of publication.

No reliance or warranty

This Guide does not constitute legal or business advice, and should not be relied on as a substitute for obtaining detailed advice about the National Gas or Electricity Law, the Rules or any other applicable laws, procedures or policies. While AEMO has made every effort to ensure the quality of the information in this Guide, neither AEMO, nor any of its employees, agents and consultants make any representation or warranty as to the accuracy, reliability, completeness, currency or suitability for particular purposes of that information.

Limitation of liability

To the maximum extent permitted by law, contributors to this Schedule (or their respective associated companies, businesses, partners, directors, officers or employees) are not liable (whether by reason of negligence or otherwise) for any errors, omissions, defects or misrepresentations in this document, or for any loss or damage suffered by persons who use or rely on the information in it.

Copyright

Copyright 2017 Australian Energy Market Operator Limited. The material in this publication may be used in accordance with the [copyright permissions](#) on AEMO's website.

Distribution

Available to the public.

Last update

1 June 2016

Further information

For further information, please visit www.aemo.com.au or contact:

AEMO Information and Support Hub

Phone: 1300 AEMO 00 (1300 236 600) and follow the prompts.

Email: supporthub@aemo.com.au

1 Introduction

1.1 Purpose

This schedule is used to define the default direction for all BB pipelines.

This document is written in plain language for ease of reading. Where there is a discrepancy between the [National Gas Rules](#) or the [Exchange Agreement](#), and information or a term in this document, the National Gas Rules or Exchange Agreement take precedence.

1.2 Audience

This schedule is relevant to all users of the Natural Gas Services Bulletin Board website, including those that upload data to the website.

For a more detailed explanation of the GBB Website, see [Guide to GBB Website](#).

For a more detailed explanation of CSV file transactions, see [Guide to GBB CSV File Transactions](#).

For a more detailed explanation of the [Reports](#) published on the GBB website, see [Guide to GBB Reports](#).

2 Default Pipeline Flow Direction

2.1 Forecast Pipeline Flows

For the Forecast Pipeline Flows (INT 923) report, positive quantities represent net flow from Plant to Zone, while negative quantities represent net flow from Zone to Plant. In the case of a Plant that has its own Zone, such as the Moomba to Sydney Pipeline System ('MSP'), this mean that gas delivered to the MSP Zone by the MSP pipeline is reported as positive.

2.2 Capacity Default Flow Direction

For capacity related reports (INT 911, 914, 922, 928 and 929), the capacity of a pipeline in the default flow direction as defined in the schedule below aligns with MDQ and TRANC, and the capacity of a pipeline in the reverse flow aligns with RMDQ and REVC. Note that the sign of the capacities represented on the map of the homepage does not follow this rule as they are configured to align with the Forecast Pipeline Flows (as noted above).

2.3 Schedule of Default Flow Direction for Pipeline Capacity

Pipeline Name	Default Flow From	Default Flow To
Eastern Gas Pipeline	Gippsland (Longford)	Sydney
Moomba to Sydney Pipeline System	Moomba	Sydney
NSW-Victoria Interconnect (part of the DTS)	Victorian DTS (Melbourne)	Moomba to Sydney Pipeline (Culcairn)
Longford to Melbourne (part of the DTS)	Gippsland (Longford)	Victorian DTS (Melbourne)
South West Pipeline (part of the DTS)	Port Campbell (Iona)	Victorian DTS (Melbourne)
Roma - Brisbane Pipeline	Wallumbilla	Brisbane
Queensland Gas Pipeline	Wallumbilla	Gladstone and Rockhampton
Carpentaria Pipeline	Ballera	Mt. Isa
South West Queensland Pipeline	Wallumbilla	Moomba
SEA Gas Pipeline	Port Campbell (Iona)	Adelaide
Moomba to Adelaide Pipeline System	Moomba	Adelaide
Tasmania Gas Pipeline	Gippsland (Longford)	Hobart
Wallumbilla to Gladstone Pipeline	Roma	Curtis Island LNG
APLNG Pipeline	Roma	Curtis Island LNG
GLNG Gas Transmission Pipeline	Roma	Curtis Island LNG
Berwyndale to Wallumbilla Pipeline	Roma (Berwyndale)	Wallumbilla
Darling Downs Pipeline	Darling Downs	Wallumbilla
Comet Ridge to Wallumbilla Pipeline	Wallumbilla	Roma (Comet Ridge)
Spring Gully Pipeline	Spring Gully	Wallumbilla

3 References

The following resources may be helpful:

3.1 Rules, Law, and Government Bodies

The Australian Energy Market Commission (AEMC) makes rules under the National Gas Law, the National Electricity Law and the National Energy Retail Law that must be followed by all participants in the Australian energy market (excluding WA and NT). The National Gas Rules can be found on the AEMC website: <http://www.aemc.gov.au/Energy-Rules/National-gas-rules/Current-rules>

The Australian Energy Regulator (AER) oversees compliance by participants in the Australian Energy Market with the National Gas Law and National Gas Rules: www.aer.gov.au

The Gas Supply Hub Exchange Agreement can be found on AEMO's website: <http://www.aemo.com.au/Gas/Market-Operations/Gas-Supply-Hub/Join-the-Market>

3.2 Relevant Documents and Guides

User guides for the Gas Bulletin Board can be found within the Bulletin Board Information Tab on the GBB website, (here: <https://gbb.aemo.com.au/Bulletin%20Board%20Information/Documents.aspx>).

This includes:

- Guide to GBB CSV File Transactions – detailed explanation for uploading CSV Files to provide data to AEMO for the GBB website
 - Guide to GBB Reports – detailed explanation for accessing, viewing, and saving data reports available on the GBB website
 - GBB Participation Registration Kit – information for prospective participants in the GBB and National gas systems
 - GBB Procedures – the procedures that regulate the operation of the GBB website
 - Guide to GBB Website– guide to using the GBB website
 - Guide to Using the Self Service Password Management Facility – guide for how to use the self-service password management facility, once registered, for those with secure access only
 - Guide to Register to use the Self Service Password Management Facility – guide for how to register to use the self service password management facility, for those with secure access only
 - Schedule of Default Pipeline Flow Direction (this document) – schedule that defines the default direction for all BB Pipelines.
-

If you require further assistance or information, please contact the AEMO Information and Support Hub:

Telephone: 1300 AEMO 00 (1300 236 600)

Email: supporthub@aemo.com.au
